

Assembling Helios EHWP2/7 - mobile infrared heater



Here we see the individual parts that we took out of the packaging:

- The radiator
- The stand (in the middle)
- The bracket with soft grip

You need for the assembly:

- 2x spanner size 10 (not supplied)



Now loosen the two protruding screws on the lower part of the spotlight to remove the oval guide.

To do this, hold the screw head with one spanner and loosen the nuts counterclockwise with the other spanner.



Now put the oval guide over the retaining bracket until the holes are on top of each other. In the picture, this is further to the right.



Now you can attach the bracket to the spotlight. To do this, insert the two screws from below the radiator.

Then insert the screws through the two holes in the bracket with the oval guide.

You may have to raise the spotlight a little so that you can attach the grab rail neatly.



Here we now see the retaining bracket with the oval guide at the bottom of the spotlight with the two screws going through all the parts.

Now put the washers over the screws first and then the nuts.



Now tighten the nuts firmly by holding the head end of the screw against it again and tighten the nuts.



Now, from the opposite direction, insert the upright into the oval guide.

Do this in such a way that you can fix the wing bolt to the oval guide. As can be seen here in the picture below.

The wing screw must be at the front of the spotlight at the end.



Congratulations!

You have successfully assembled the spotlight.



If you have any questions, please do not hesitate to contact us.

Yours sincerely, ecofort team